


MINI GLO-BALL S

Designed by Jasper Morrison, 1998


F4195009



MINI GLO-BALL S

F4195009

EN



01. RF6256001 – Ceiling rose assembly

02. RF4190200 – 5 meter Sil/Fep transparent cable 2x0.75

03. RF12818 – G9 5600 lamp holder

04. RF4195200 – New type Mini Glo-ball S diffuser assembly

MINI GLO-BALL S F4195009

EN

RF6256001

CEILING ROSE ASSEMBLY



Ktribe
S1
p.03



Mini
Glo-Ball
S
p.03

WARNING! When installing and whenever acting on the appliance, ensure that the power supply has been switched off.
For the installation of the spare-part, it is necessary to consult a qualified electrician.

MINI GLO-BALL S F4195009

EN

RF6256001

CEILING ROSE ASSEMBLY




Fig.1

Fasten the wall fitting to the ceiling with screws and screw anchors, making sure the power cables pass through the central hole. Utilize the 3 protection covers (F) to cover the screws.

NOTE: Choose screw anchors that are suitable for the type of mounting surface.

MINI GLO-BALL S F4195009

EN

RF6256001

CEILING ROSE ASSEMBLY




Fig.2

Connect the main power supply wires to the terminal block (C). Put the protection sheath (G) that has been supplied with the device through the power cable (E); thread the power cable (E) through the specific wall fitting opening (B), adjust (if necessary) the device height, lock the cable through the cable tighter present near the opening (B) and then cut off the excess cable.

WARNING! When installing and whenever acting on the appliance, ensure that the power supply has been switched off.
For the installation of the spare-part, it is necessary to consult a qualified electrician.

©2021 Flos - All rights reserved - www.flos.com
Flos reserves the right to introduce any changes to its own models, without prior notice.

MINI GLO-BALL S F4195009

EN

RF6256001

CEILING ROSE ASSEMBLY




Fig.3

Position the protection sheath (G) at the height of the screw (D), then lock the power cable by tightening the screw (D). Connect the electrical cable wires to the terminal block (C). Assemble the ceiling rose cover (A) onto the wall mounting (B) ensuring that the small moulded column (H) corresponds with the opening (I) of the ceiling rose cover.


WARNING! When installing and whenever acting on the appliance, ensure that the power supply has been switched off.
For the installation of the spare-part, it is necessary to consult a qualified electrician.

MINI GLO-BALL S F4195009


EN

RF4190200

5 METER SIL/FEP 2X0,75 TRANSPARENT ELECTRICAL CABLE



Ktribe S2
p.06



Ktribe S3
p.06



Mini
Glo-Ball S
p.07



Ray S
p.08



Romeo
Babe
p.08



Romeo
Babe Soft S
p.08

WARNING! When installing and whenever acting on the appliance, ensure that the power supply has been switched off.
For the installation of the spare-part, it is necessary to consult a qualified electrician.

MINI GLO-BALL S F4195009


EN

RF12818

G9 5600 LAMP HOLDER



Mini
Glo-Ball S
p.08



Mini
Button
p.03

WARNING! When installing and whenever acting on the appliance, ensure that the power supply has been switched off.
For the installation of the spare-part, it is necessary to consult a qualified electrician.

MINI GLO-BALL S F4195009

EN

RF12818

G9 5600 LAMP HOLDER




Fig.1

Unfasten the diffuser (A) from the support (B) by utilizing a coin or similar object, if necessary.

WARNING! When installing and whenever acting on the appliance, ensure that the power supply has been switched off.
For the installation of the spare-part, it is necessary to consult a qualified electrician.

©2021 Flos - All rights reserved - www.flos.com
Flos reserves the right to introduce any changes to its own models, without prior notice.

MINI GLO-BALL S F4195009

EN

RF12818

G9 5600 LAMP HOLDER




Fig.2

Remove the lamp-bulb (C).
Free the lamp holder (D) from the support (B) by unfastening the two screws (E).

WARNING! When installing and whenever acting on the appliance, ensure that the power supply has been switched off.
For the installation of the spare-part, it is necessary to consult a qualified electrician.

MINI GLO-BALL S F4195009

EN

RF12818

G9 5600 LAMP HOLDER



Fig.3




Fig.4

Disconnect the electrical wires (G) from the lamp holder by pressing the push terminals with a paper clip (F).

WARNING! When installing and whenever acting on the appliance, ensure that the power supply has been switched off. For the installation of the spare-part, it is necessary to consult a qualified electrician.

©2021 Flos - All rights reserved - www.flos.com
Flos reserves the right to introduce any changes to its own models, without prior notice.

MINI GLO-BALL S F4195009

EN

RF12818

G9 5600 LAMP HOLDER



Fig.5




Fig.6

Assemble now the new spare-part:

Connect the electrical wires (H) to the “new” lamp holder terminals.

Connect the Brown “L” (live) wire in the terminal that corresponds to the letter “L” present on the lamp holder and then connect the Blue “N” (neutral) wire in the terminal “N”.

N.B. The electrical wires are connected by pushing the wires inside the terminals, therefore it is necessary to verify that they are connected properly.

Assemble the lamp holder (D) to the support (B) by fastening the two screws (E).

Install the lamp-bulb (C).(Fig.2 page 10)

Insert the lamp-bulb and fasten the diffuser (A).

LAMP BULB REPLACEMENT – unfasten the diffuser (A) from the support (B) by utilizing a coin or similar object, if necessary, as shown in the image.(Fig.1 page 9)

WARNING! When installing and whenever acting on the appliance, ensure that the power supply has been switched off.
For the installation of the spare-part, it is necessary to consult a qualified electrician.

MINI GLO-BALL S F4195009

EN

RF4195200

NEW TYPE MINI GLO-BALL S DIFFUSER ASSEMBLY



WARNING! When installing and whenever acting on the appliance, ensure that the power supply has been switched off.
For the installation of the spare-part, it is necessary to consult a qualified electrician.

©2021 Flos - All rights reserved - www.flos.com
Flos reserves the right to introduce any changes to its own models, without prior notice.

MINI GLO-BALL S F4195009

EN

RF4195200

NEW TYPE MINI GLO-BALL S DIFFUSER ASSEMBLY




Fig.1

Insert the lamp-bulb and fasten the diffuser (L).

LAMP BULB REPLACEMENT – unfasten the diffuser (L) from the support (M) by utilizing a coin or similar object, if necessary, as shown in the image.

WARNING! When installing and whenever acting on the appliance, ensure that the power supply has been switched off.
For the installation of the spare-part, it is necessary to consult a qualified electrician.

©2021 Flos - All rights reserved - www.flos.com
Flos reserves the right to introduce any changes to its own models, without prior notice.